

POPCORN MACHINE INSTRUCTIONS



INSERT KETTLE

1. Hold the kettle with black knob facing towards you
2. Slightly tip the kettle on an angle while inserting it into the two 'J' shaped hooks, the gears should match up at the top
3. Plug the kettle into the roof of the machine

POPPING INSTRUCTIONS

1. Turn the 'kettle heat', 'kettle motor' & 'light/warmer' switches to ON
2. Test pop with 3 kernels of corn & 1 ounce of popping oil, kettle is ready when kernels pop
3. Load corn, oil and seasoning salt into the kettle
4. When corn has popped, dump out the kettle & refill it
5. On the final kettle of corn, turn the 'kettle heat' switch OFF just as the lid is forced open by the popping corn - this will eliminate smoke & odour once the corn has stopped popping

MEASUREMENTS



8OZ
PACKAGE

=



10
SERVINGS

CLEANING INSTRUCTIONS

1. Allow kettle to cool completely before handling, then unplug it and remove it from the machine
2. Wipe the kettle, kettle lid, crossbar and the machine exterior with a cloth **DO NOT IMMERGE THE KETTLE IN WATER**
3. Remove any leftover popcorn from machine
4. Remove, empty and wipe the pan clean
5. Wipe interior of the machine clean with a cloth

Return the machine clean to A&B to avoid a cleaning fee